


IV. Dimension:



V. Exception handles

Fault Case	Reasons	Solutions
No light	<ol style="list-style-type: none"> 1、 No power from plug 2、 At black mode 3、 The fuse broken 4、 Incorrect connection 	<ol style="list-style-type: none"> 1、 Change the socket 2、 Change the running mote 3、 Replace the fuse 4、 Check the connection
incorrect Color	<ol style="list-style-type: none"> 5、 Wrong RGB connection 	<ol style="list-style-type: none"> 5、 Check RGB connection
Non synchronous	<ol style="list-style-type: none"> 6、 Wrong sync cable connection 	<ol style="list-style-type: none"> 6、 Check sync cable connection

